

Instructions & Tips for Spartan.ist Motorcycle Saddlebags

What's Included ?



- 1x Set - Left And Right Saddlebags
- 2x Saddlebag Rain Covers
- 2x Seat Attachment Webbing Straps (A)
- 1x Bottom Of Bag (Bag to Bag) Securing Webbing Strap (B)
- 4x Frame Attachment Webbing Straps (C)
- 2x Flat Plastic Strips, Which Are Bag Inserts To Improve Bag Rigidity (D)

How to mount to motorcycle ?

FITTING

1. Insert plastic strips (D) into pockets to improve rigidity.



2. Attach seat straps (A) around the seat, put seat back in place.



3. Refer to separate image - connect bags to seat straps.

4. Secure the bag flaps by closing velcro (hook and loop strips).



5&6. Secure bag to footrest using strap (C), and then bag-to-bag with strap (B).

6a. (Optional) Use strap (C) to secure back of bag to frame.



1. Inside each bag there are two "pockets" - Insert one flat plastic strip (D) into each pocket - this improves the bag's rigidity, repeat for second saddlebag.

2. Lift seat and attach seat attachment straps (A) x2 around the seat, and secure seat back in place.

3. See next section.

4. Secure the bag flaps by closing Velcro (hook and loop strips), one on top of the other, for added security.

5. Secure bags at bottom (front) using frame attachment straps (C), back footrests are a good point to attach, close the quick release buckles, and adjusting straps as necessary.

6. Secure bag to bag (bottom rear of bags), using quick release buckles with strap (B), and adjusting straps as necessary. In this case straps x 2 (C) will not be used.

6a. Alternative, rather than bag to bag, secure bags at back using frame attachment straps (C). In which case strap (B) will not be used.

Fitting (Part 3)



3. Attach the quick release buckles (on attachment straps (A)) to the top of the bags on either side of the bike, first push the open buckle through the holes in the flap, then looping the strap through the "D" ring and snap buckle closed.

Tips

- The frame attachment straps are best fitted by looping the end of strap through the loop, and around an attachment point (frame/footrest)
- Please ensure the bags have a clearance of at least 2 inches from exhaust to prevent heat from damaging the bags.
- For safety, please ensure bag and straps cannot come into contact with the wheel or chain/belt.
- Install the bag with reflective strips facing the rear of the bike. This positioning helps prevent wind from loosening Velcro fastenings and keeps your contents secure, and also the reflective strip help to be visible at night.
- Please reach out to us with any questions, and we will be glad to help you revolve. We're always glad to receive feedback, as it helps improve our products and procedures.